

CONTENTS

Section 1 Receiving the TX2003

- 1.1 Safety notices
- 1.2 Standards

Section 2 Introducing the TX2003

- 2.1 TX2003 features
- 2.2 Specifications
- 2.3 Accuracy

Section 3 First operations

- 3.1 Preparing the TX2003
- 3.2 Menu & screen displays
- 3.3 Set auto shutdown
- 3.4 Set unit of measure
- 3.5 Set cable impedance
- 3.6 Set Velocity of propagation
- 3.7 Backlight
- 3.8 How to determine unknown Vp Settings

Section 4 Using the TX2003

- 4.1 Testing a cable
- 4.2 Selecting range scales
- 4.3 Single shot and Continuous scan mode
- 4.4 Tone generator
- 4.5 Adjusting contrast
- 4.6 Typical fault displays
- 4.7 Typical Cable Vp & Impedance values

Section 5 Maintenance

- 5.1 Battery replacement
- 5.2 Cleaning
- 5.3 Storage

Section 6 Warranty & Repair

- 6.1 Contacting us



Section 1 Receiving the TX2003

Upon delivery of the TX2003, ensure the contents are consistent with the packing list, notify your supplier of any missing items.

If the equipment appears damaged, notify your carrier and supplier immediately, giving a detailed description of any damage, save the damaged packaging to substantiate your claim.

The TX2003 includes a 0.5 mtr test lead, soft case and user manual.

1.1 Safety notices

**Warning**

- This instrument meets the safety requirements of IEC61010-1: 1995
- The TX2003 is designed for use on de-energized circuits only.
- Connection to line voltages will damage the instrument and could be hazardous to the operator
- This instrument is protected against connection to telecom network voltages according to EN61326-1.
- Safety is the responsibility of the operator

International Electrical Symbols



This symbol signifies that the instrument is protected by double or reinforced insulation. Use only on specified replacement parts when servicing the instrument.



This symbol on the instrument indicates a WARNING then the operator must refer to the user manual for instructions before operating the instrument. In this manual, the symbol preceding instructions indicates that if the instructions are not followed, bodily injury, installation/sample and product damage may result.



Risk of electric shock. The voltage of the parts marked with this symbol may be dangerous.

1.2 Standards

The TX2003 has been manufactured in accordance with and meets the requirements of the following international standards:

SAFETY	IEC 61010-1 EN 60950
EMC	BS/EN 61326-1
Water/Dust Proof	to IP54

Section 2 Introducing the TX2003

The TX2003 is a 6,000 meter (19,000ft) range, hand held, time domain reflectometer weighing only 350 grams (12 ounces) designed for identifying and locating faults on Metallic power, Data and Communication cables, with a 7 mtr first range scale and 0.5 mtr dead zone, is ideal for locating near end faults.

The TX2003 injects a series of pulses into the cable under test, the velocity at which the pulses travel is determined by the type of cable, this is known as the velocity of propagation (Vp) of the cable.

The Vp value is expressed as a percentage of the speed of light i.e. 67% or ft/mtrs/micro second (ms), this value will vary according to the type of cable under test, the TX2003 can accept user selectable values between 1 and 99% (or the equivalent value in feet or meters per micro second).

Based on the selected Vp and the time taken for the pulses to travel through the cable, a reflection profile of the cable under test is displayed, identifying impedance anomalies along the cable by aligning the moveable cursor to the selected anomaly the distance to fault is displayed in feet or meters.

2.1 TX2003 Features

1. BNC Input connector
2. LCD Start up screen
3. Cursor left key / increase range
4. Cursor right key / decrease range
5. Menu and range select button
6. Test start key
7. Power on/off button
8. Back light on/off button

2.2 Specifications

Ranges Meters	7, 15, 30, 60, 120, 250, 500, 1km, 2km, 3km, 6km
Feet	23, 49, 98, 197, 394, 820, 1640, 3280, 6560, 9850, 19000
Range Selection	Manual range control
Accuracy	1% of selected range*
Resolution	Approx 1% of range
Sensitivity	Min 3 pixel return at 4km on 0.6mm Ø, PE, TP
Velocity Factor	Adjustable from 1% to 99%
Output Pulse	5 volts peak to peak. Into open circuit
Output Impedance	Selectable 25, 50, 75 & 100 ohms
Output Pulse Width	3 ns to 3 ms, Automatic with range
Scan Rate	2 scans / second or scan held
Tone Generator	810 – 1100Hz
Battery Life	60 hours continuous scanning
Power Supply	6 volts 4 x 1.5 AA Alkaline cells
Power Down	Selectable 1, 2, 3, 5 minutes or disabled
Back Lit Display	128 x 64 pixel
Voltage Protection	250 volts AC
Operating Temp	-10° / 50°C
Storage Temp	-20° / 70°C
Dimensions	165 x 90 x 37 (6.5 x 3.5 x 1.5 ins)
Weight	350 gms (12oz)
Safety	IEC 61010-1 EN 60950
EMC	BS/EN 61326-1
Water/Dust Proof	IP54

* Measurement accuracy of $\pm 1\%$ assumes the instrument setting for velocity of propagation (V_p) of the cable under test to be accurately set, homogeneity of the V_p along the cable length, and accurate cursor positioning.

2.3 Accuracy

The TX2002 is able to measure distances to faults and cable lengths to an accuracy of $\pm 1\%$.


This measurement accuracy is based on the correct value of V_p being used for the cable under test, and homogeneity of the V_p along the cable length.


If the V_p is set incorrectly by the operator, or the V_p varies along the length of the cable, then additional errors will be incurred and the measurement accuracy will be affected.

Note:- The V_p is less well defined with unshielded multicore cable, including power cable, and is lower when a cable is tightly wound on a drum than when installed.

Section 3 First Operation

3.1 Preparing the TX2003 for use

Press button  to power the tester, the following screen will be displayed:




- 1 Model
- 2 Software version programmed into tester
- 3 Battery condition indicator (all black battery, fully charged, as charge decreases symbol changes to white) Battery condition indicator is permanently displayed.


Prior to use the following parameters will need to be set

- 1 Auto shutdown section 3.3
- 2 Set contrast section 4.5
- 3 Select unit of measure section 3.4
- 4 Select velocity of propagation section 3.7

3.2 Menu and Screen Displays

Level 1. Start up screen


To access level 2 menu. Press down TDR button and hold, press  release both buttons. To exit press TDR button.







Level 2. Menu




3.3 Set Auto Shutdown







To preserve battery life, the TX2003 is fitted with an auto shutdown feature. Shutdown time is selectable between disabled 1 minute, 2 minutes and 3 minutes.

To change settings press  to move  to shutdown use  or  to select setting.

3.4 Set Unit of Measure (Level 2)







Press  to move  to unit of measure (feet or meters).
Press  or  to scroll between feet and meters.
Press TDR button to exit, selected value will be automatically stored.

Note:- When unit of measure has been selected, this will automatically change the V/2 figure, which will also be displayed in the selected unit of measure.

3.5 Set cable Impedance (Z)


The cable impedance (Z) is selectable for 25, 50, 75 or 100Ω Twisted pair (T/P)










Press  to move cursor  to Z, to scroll between values press  or  To exit press TDR, selected values will be automatically stored.

3.6 Set Velocity of Propagation (Vp) Level 2

Velocity of propagation (Vp) may be set as % or speed in micro seconds (ms). The unit of measure, the speed is displayed in (feet or meters), will be determined by the setting selected in section 3.4



Press  to move  to displayed unit, press  to scroll between v/2 M/Ms or Vp % UC.

Press  to move  to displayed unit, press  or  to increase or decrease displayed value, press TDR to return to screen. Selected values will be automatically stored

3.7 Backlight


The LCD display is fitted with an electro-luminescent backlight to enable easy viewing under a variety of different lighting conditions. The backlight is switched on and off with the X key.


Section 3.8 How to determine Vp settings

If the TDR TX2003 is to be used with a cable type for which the Vp is unknown, this must first be determined.

1. Take a sample of the cable at least 100m or 300ft long.
2. Measure the actual length of cable using a rule or tape measure, or some other reliable method.
3. Connect the TDR TX2003 and adjust the Vp setting such that the tester gives a correct reading of the sample length.

Section 4 Using the TX2003

Upon completion of the set up procedures in section 3, press button  and the following test screen will be displayed



1. Vp Setting
2. Impedance setting (Z)
3. Range scale 7 mtrs
4. Battery condition indicator
5. Distance of cursor
6. Cursor
7. Output pulse
8. Scan mode icon (indicating scan mode selected)



Attach the test lead set to the TX2003 via the BNC connector located at the top of the unit,

1. Ensure that no power supply or equipment is attached to the cable to be tested
2. Ensure that the far end of the cable under test is open or shorted (not fitted with a resistive termination)
3. Attach the TX2003 to one end of the cable to be tested

Coaxial Cable: Connect the red clip to the centre wire and the black clip to the shield/screen.


Shielded Cable: Connect the red clip to a wire adjacent to the shield and the black clip to the shield.

Twisted Pair: Separate out one pair and connect the red and black clips to the two wires of the pair.

Multicore Cable: Connect the clips to any two wires.

4.1 Testing a cable

Having followed the set up procedures in the preceding sections, a typical display showing impedance anomalies is shown below. Further examples are shown in section 4.6.



The vertical cursor line is moved left or right along the line of the trace by pressing ◀ and ▶ buttons to determine the distance to the event. Position the cursor at the beginning of the event and read off the distance at the bottom left corner.

On the fault display shown above a low impedance fault occurs at 64 meters shown by a negative spike, and a high impedance at 129 meters. The open end of the cable is shown as a large positive spike, this is used to determine the end of the cable run and the overall length of the cable being 180 meters.

4.2 Selecting Range Scales

The TX2003 has 11 range scales covering the range of 0.5 to 6,000 meters.

To select a range scale, or scan the cable run, press and hold down the TDR button and press ◀ to decrease range, press ▶ to increase range.

4.3 Single shot and Continuous Scanning Modes

When the TX2003 is first switched on, it is set to “Single Shot” mode.

In this mode the TX2003 only fires a pulse into the cable under test when either the ◀ and ▶ buttons or ▼ button is pressed.

Single Shot Mode: Saves on battery life and also enables the TX2003 to be disconnected from the cable while still leaving the fault display on the screen

To enter “**Continuous Scanning**” mode press down and hold the ▼ button.

The icon will appear at the bottom right of the display, when continuous scanning mode is activated.

Continuous Scanning Mode: fires pulses into the cable under test. In this mode the TX2003 is able to more easily identify intermittent cable faults.

4.4 Tone Generator

The TX2003 may also be used as a tone generator to trace and identify cables and wires. The user will need a conventional inductive tone probe within the range 810 Hz to 1110Hz.

To select tone generator (Level 2)




Press ▼ to move → to TDR, press ◀ to scroll between TDR and warble. Press TDR button to exit.

When tone has been selected, connect test lead to cable pair to be traced and using tone probe which will emit a tone, the volume will increase the nearer the probe is to the cable / being traced.

Note:- The auto off function is disabled in tone generator mode so that the tone can be injected into a cable for extended periods while tracing takes place.

4.5 Set Contrast (level 2)



Press ▼ to move → to contrast. Press ◀ to decrease contrast, press ▶ to increase contrast. **Press TDR button to exit.**

4.6 Typical Fault Displays

The following diagrams show typical fault traces to assist you in the identification of faults using the TX2003:

4.7 Typical Cable V.P and Impedance Values

Type	Vp	Z	Type	Vp	Z
Cat5 STP	72	100	T/Pair Jelly PE	64	100
Cat5 UTP	70	100	T/Pair PE	67	100
Coax Air	98	50/75	T/Pair PTFE	71	100
Coax Air Space	94	50/75	T/Pair PVC	58	100
Coax Foam PE	82	50/75	T/Pair Paper 72nF	88	100
Coax Solid PE	67	50/75	T/Pair Paper 83nF	72	100

Section 5 Maintenance

5.1 Battery Replacement



Disconnect the instrument from any cable or network link

- Turn the instrument off
- Loosen the two black screws and remove the battery compartment cover
- Replace the batteries with 4 x 1.5 volt Alkaline batteries, observing the polarities
- Refit the battery compartment cover and refit the two screws

5.2 Cleaning



Disconnect the instrument from any source of electricity

- Turn the instrument off
- Use a soft cloth lightly dampened with soapy water, wipe over the instrument, rinse the cloth in clean water squeezing out any excess water, wipe over the instrument removing any soap residue, dry instrument with a dry cloth
- Do not splash water directly on the instrument
- Do not use alcohol, solvents or hydrocarbons

5.3 Storage



If the instrument is not to be used for a period of more than 60 days, it is recommended that the batteries are removed and stored separately (see 5.1)

Section 6 Repair and Warranty

The instrument contains static sensitive devices and is not user serviceable. If an instrument fails, or its protection has been impaired, it should not be used but sent back for repair by suitably trained and qualified personnel.

New instruments are guaranteed against breakdown due to manufacturing or component defects for 12 months after the purchase date by the user.

Note:- Any unauthorized prior repair or adjustment to the instrument will automatically invalidate the warranty.

6.1 Contacting Us

**BI Communications Ltd
Unit 7 Buckwins Square
Burnt Mills Industrial Estate
Basildon
Essex
SS13 1BJ**

**Tel: 01268 729393
Fax: 01268 727987
Email: bicomms@dircon.co.uk**